HELIX



VOICE REMOTE USER GUIDE

Basic features

HELIX Access the main menu

During viewing





In menus



Navigating in menus



Exiting menus

Shortcuts



Help and Troubleshooting section



Accessibility Settings, such as Closed Captioning



During viewing, access the Sports Zone



From the Recordings menu, Delete a recording

How to link your voice remote to another Helix TV terminal

- Press and hold buttons A and D until the voice remote's light changes from red to green.
- Press 9-8-1.
- Press the Mic button.
- Follow the instructions on the screen to finish pairing the voice remote with your TV or audio system.

Voice commands

For voice command, press and hold the Mic button.

Examples of voice commands

- Weather
- What should I watch
- CF Montréal
- Action movies
- Subtitles
- Funniest videos on YouTube
- Fast-foward/rewind 30 seconds

Ensure your experience is secure

With voice command, say "Settings"

- Select "Parental Control" if you want to limit access to adult content.
- Select "Purchase PIN" to prevent unwanted or impulse purchases.

TV Guide









To filter









Quickly scroll through the TV Guide



Simplified Guide



Press the right arrow to display the simplified guide while continuing to watch your content.

Press it a second time to display the selected channel's details.

Movies and series On Demand

HELIX then On Demand



Recording shows

Live show




and confirm



Programming a recording

From the TV Guide or using voice command:

1. Select the series or show.







For a series, choose between

"Just this episode" or "All episodes," and confirm:

. New episodes only:

record only the first broadcast (all languages).

· New and rerun episodes: record all broadcasts.

Viewing your recordings



HELIX then Saved then Recordings



or **Q** "Recordings"

· 1. TV Input

TV Input

VOL

Exit

Power

CH

 \vee

>>

Mute

 $\triangleright ||$

Guide HELIX PG

O Space

>

Goes to the next input of your TV

2. Mic/LED status

3. Record

Starts recording the show that's playing or lets you schedule a recording in the Guide

4. Page Up/Page Down

Lets you skip ahead in the Guide and skip forward/back when watching recordings or On Demand content

:····· 5. HELIX menu

Lets you access search, settings, On Demand content, your recordings, apps, and the Guide

6. Guide

Displays the Program Guide

7. Navigation pad

Middle button: selects an item on the screen Arrows: used to navigate the screen

- A: Displays the Help menu
- B: Displays accessibility settings
- C: Launches the Sports Zone
- D: Deletes a recording or a group of recordings

8. Back arrow

Goes back to the previous screen Displays your previous 9 viewings while you're watching your current content

9. Mic button

Activates voice command

10. Info

Displays detailed information about the TV program

Anywhere, anytime

Download the Helix TV app

- Program and view your recordings
- Download your recordings to view them without an Internet connection
- Watch your shows live and on demand





You can also watch your shows on your computer helix.videotron.com

Need help?

To learn more about the voice remote go.videotron.com/voice-remote





